

Bladerunner Installation Instructions

Step 1: Remove discs

1. Invert the mower on a soft surface.
2. Using the supplied allen key, remove the 3 hex-head screws attaching each disc to the motor hub.
3. Lift off the discs, being careful with the cutting blades if they are still attached.
4. Now is a good time to inspect the motor shaft for any debris caught around it. If there is vegetation built up it may be a good idea to remove the hub from the motor to get access to the shaft. A 10mm socket and some multi grips can be used to remove the nut and the hub then lifts off.



Step 2 (Optional): Install *GuardFree* motor covers

1. To remove your blade guards and install the *GuardFree* covers, start by using the allen key to remove the 3 mounting screws from the center of the guards where they attach to the motor.
2. Lift off the guards and put them aside.
3. Place the *GuardFree* covers in place - they will only go on one way with the bottom of the text facing to the outside of the mower.
4. Insert the supplied hex-head screws and tighten down with the allen key.



Step 3: Install *Bladerunner* discs

1. Place the *Bladerunner* discs on top of the motor hubs, ensuring the holes in the disc are aligned with the threaded holes in the hub.
2. Insert the supplied hex-head screws and tighten down with the supplied allen key.
3. Attach the blades using the supplied screws.

