

GuardFree Installation Instructions

Step 1: Remove discs

1. Invert the mower on a soft surface.
2. Using the supplied allen key, remove the 3 hex-head screws attaching each disc to the motor hub.
3. Lift off the discs, being careful with the cutting blades if they are still attached.
4. Now is a good time to inspect the motor shaft for any debris caught around it. If there is vegetation built up it may be a good idea to remove the hub from the motor to get access to the shaft. A 10mm socket and some multi grips can be used to remove the nut and the hub then lifts off.



Step 2: Install *GuardFree* motor covers

1. To remove your blade guards and install the *GuardFree* covers, start by using the allen key to remove the 3 mounting screws from the center of the guards where they attach to the motor.
2. Lift off the guards and put them aside.
3. Place the *GuardFree* covers in place - they will only go on one way with the bottom of the text facing to the outside of the mower.
4. Insert the supplied hex-head screws and tighten down with the allen key.



Step 3: Reinstall discs

1. Place the discs on top of the motor hubs, ensuring the holes in the disc are aligned with the threaded holes in the hub.
2. Fix the disc with the original screws.

